



LEGENDEX ROGUE M.O.L.L.E

PRODUCT CODE: MR-76-B-1

76 Series Land Cruiser UHF Mount Bracket



LEGENDEX.COM.AU (07) 3203 2333

INSTALLING YOUR NEW ROGUE M.O.L.L.E

STEP 1

Open the door and identify where the bracket will sit



FOR
REFERENCE
THE IMAGE 1 IS
OF A BRACKET
INSTALLED AND
IMAGE 2 IS OF
NO BRACKET
INSTALLED



STEP 2

NOW YOU WILL NEED TO MARK THE HOLES YOU NEED TO DRILL BY HOLDING THE BRACKET IN PLACE AND USING A MARKER, MARK OUT THE 2 HOLES.

STEP 3

THEN DRILL OUT THE TWO HOLES, AND APPLY AN ANTI-RUST SPRAY TO THE FRESH DRILL HOLES. NEXT USE A RIVET NUT ON THE TWO HOLES JUST DRILLED. THEN BOLT YOUR BRACKET INTO PLACE.

STEP 4

THEN INSTALL YOUR UHF ONTO THE BRACKET



